

## Diamond Single Seat Valve Installation & Maintenance: ATEX Directive 2014/34/EU & The Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres Regulations 2016 SI 1107

Page 1 of 1


## ADDITIONAL INSTRUCTIONS TO BE USED IN CONJUNCTION WITH INSTALLATION & MAINTENANCE INSTRUCTIONS FOR DIAMOND SINGLE SEAT VALVES

## **IMPORTANT - PLEASE READ CAREFULLY BEFORE INSTALLING YOUR UNIT**

ATEX / Equivalent UK regulations compliant valves that support the "Ex" compliance symbol pictured below are fitted with an additional component that is essential to the safe operation of the unit in hazardous environments. When valves are dismantled for installation or maintenance it is important that they are correctly reassembled, with the Earthing Spring in place, as depicted below. The valve shown below is a <a href="Single Body">Single Body</a> seat valve. The same principle applies for <a href="Double Body">Double Body</a> valves. The earthing spring is fitted over the valve shaft and beneath the coupling, in the position shown below on both single and double body variants. The following points must be adhered to when maintaining / installing an ATEX / Equivalent UK regulations Single Seat Valve:

- 1. When maintenance is performed and the Earthing Spring is removed, it must be re-fitted as shown below. Metal to metal contact must be made between the end cap, the earthing spring, and coupling to ensure electrical conductivity is achieved.
- 2. Once assembled, check that there is electrical conductivity between the actuator spindle and valve body. A multi-meter should be used to perform this test. If no conductivity exists, the valve should not be used.

**Important Note:** Pipework that is to be connected to DPL ATEX / equivalent UK regulations compliant valves must be earthed.



a **stainless** technologies company

Call us: 01799 58 2440 email us: dairypipelines@dpluk.co.uk
Visit us at: www.dpluk.co.uk Tipton Road, Dudley, West Midlands DY1 4SQ